



# ConnectCore 6UL

SBC Pro

---

Hardware Reference Manual

## Revision history—90001531

| Revision | Date          | Description   |
|----------|---------------|---|
| 1P       | November 2016 | Initial release   |
| A        | May 2017      | Add antenna section, I/O Expander section, additional power interfaces, power consumption data, and pinout comments   |
| B        | June 2017     | Modify regulatory and certification information as required by RED (Radio Equipment Directive)  |
| C        | July 2017     | Update I2C interface table, add known issue re: LCD interface wake-up when connecting Fusion 7" display, add RGB values to parallel display interface chart |
| D        | October 2019  | Add XBee note   |
| E        | November 2019 | Note swapped LINE_OUT_R and LINE_OUT_L, update images, minor edits and enhancements   |

## Trademarks and copyright

Digi, Digi International, and the Digi logo are trademarks or registered trademarks in the United States and other countries worldwide. All other trademarks mentioned in this document are the property of their respective owners.

© 2017 Digi International Inc. All rights reserved.

## Disclaimers

Information in this document is subject to change without notice and does not represent a commitment on the part of Digi International. Digi provides this document “as is,” without warranty of any kind, expressed or implied, including, but not limited to, the implied warranties of fitness or merchantability for a particular purpose. Digi may make improvements and/or changes in this manual or in the product(s) and/or the program(s) described in this manual at any time.

## Warranty

To view product warranty information, go to the following website:

[www.digi.com/howtobuy/terms](http://www.digi.com/howtobuy/terms)

## Customer support

**Gather support information:** Before contacting Digi technical support for help, gather the following information:

- Product name and model
- Product serial number (s)
- Firmware version

Operating system/browser (if applicable)

Logs (from time of reported issue)

Trace (if possible)

Description of issue

Steps to reproduce

**Contact Digi technical support:** Digi offers multiple technical support plans and service packages. Contact us at +1 952.912.3444 or visit us at [www.digi.com/support](http://www.digi.com/support).

## Feedback

To provide feedback on this document, email your comments to

[techcomm@digi.com](mailto:techcomm@digi.com)

Include the document title and part number (ConnectCore 6UL SBC Pro Hardware Reference Manual, 90001531 E) in the subject line of your email.

# Contents

---

## About the ConnectCore 6UL SBC Pro

|                                  |    |
|----------------------------------|----|
| Overview .....                   | 6  |
| Features and functionality ..... | 6  |
| Block diagram .....              | 8  |
| Placement .....                  | 9  |
| Top view .....                   | 9  |
| Bottom view .....                | 10 |
| Connectors .....                 | 11 |
| Top view .....                   | 11 |
| Bottom view .....                | 12 |
| Part numbers .....               | 12 |

## ConnectCore 6UL SBC Pro interfaces

|                                  |    |
|----------------------------------|----|
| Power interfaces .....           | 16 |
| DC-in jack connector .....       | 16 |
| Additional power connector ..... | 16 |
| Coin cell connector .....        | 16 |
| Power and reset buttons .....    | 16 |
| 5V supply connector .....        | 17 |
| 3.3V supply connector .....      | 17 |
| System boot interfaces .....     | 17 |
| Boot configuration .....         | 17 |
| Boot mode .....                  | 18 |
| Debug interfaces .....           | 19 |
| JTAG .....                       | 19 |
| SWD .....                        | 19 |
| Console port .....               | 20 |
| Communication interfaces .....   | 20 |
| NFC NTAG .....                   | 20 |
| 10/100 Mbps Ethernet .....       | 21 |
| Antenna connector .....          | 22 |
| USB Host .....                   | 23 |
| USB OTG .....                    | 23 |
| Mini PCI Express slot .....      | 24 |
| Micro-SIM .....                  | 26 |
| XBee .....                       | 27 |
| Multimedia interfaces .....      | 28 |
| Parallel display .....           | 28 |
| LVDS .....                       | 30 |

|                                       |    |
|---------------------------------------|----|
| Parallel camera .....                 | 32 |
| Audio .....                           | 32 |
| Storage interfaces .....              | 34 |
| microSD .....                         | 34 |
| eMMC .....                            | 34 |
| Additional expansion interfaces ..... | 35 |
| I/O Expander .....                    | 35 |
| CAN .....                             | 39 |
| I2C .....                             | 39 |
| SPI .....                             | 40 |
| GPIO .....                            | 41 |
| UART .....                            | 42 |
| User interfaces .....                 | 43 |
| User LED .....                        | 43 |

## ConnectCore 6UL SBC Pro specifications

|                                   |    |
|-----------------------------------|----|
| Electrical specification .....    | 45 |
| Supply voltages .....             | 45 |
| Power consumption .....           | 45 |
| Use case descriptions .....       | 45 |
| Mechanical specification .....    | 46 |
| Top view .....                    | 47 |
| Bottom view .....                 | 48 |
| Profile view .....                | 48 |
| Environmental specification ..... | 48 |
| WLAN specification .....          | 49 |

## Known issues

|   |    |
|---|----|
| Known issue: Connecting Fusion 7" display causes system to wake from suspend mode ..... | 51 |
| Affected versions/models .....  | 51 |
| Description .....   | 51 |
| Workaround/fix .....  | 52 |

## Regulatory information

|  |    |
|--|----|
| Maximum power and frequency specifications ..... | 54 |
| Europe .....                                     | 54 |
| Declarations of Conformity .....                 | 54 |
| CE mark .....                                    | 54 |

# About the ConnectCore 6UL SBC Pro

---

## Overview


The ConnectCore 6UL SBC Pro, formerly known as the ConnectCore 6UL SBC, is an ultra compact Pico-ITX board featuring the Digi ConnectCore 6UL system-on-module that integrates an NXP i.MX6UL application processor, DDR3 memory, NAND flash memory, WLAN/Bluetooth, power management IC for optimized power consumption applications, and a microcontroller assistant (MCA) for supporting additional functionality. This stand-alone product serves as the reference design for the ConnectCore 6UL system-on-module and can also be used on its own to accelerate time to market.

## Features and functionality

- ConnectCore 6UL module
  - i.MX6UL single ARM Cortex-A7 core operating at speeds up to 528 MHz
  - 16-bit DDR3-800 memory interface with a density up to 1 GB (default: 256 MB)
  - 8-bit SLC NAND flash with density up to 2 GB (default: 256 MB)
  - IEEE 802.11 a/b/g/n/ac WLAN and Bluetooth 4.2 dual mode
- Power:
  - Power jack or industrial-dedicated 5V power connector
  - Coin-cell battery charger, supplying the on-module RTC
  - Power and reset buttons
- Boot source configuration: NAND, USB
- Debug:
  - Standard IEEE 1149.1 JTAG interface
  - Single Wired Debug (SWD) interface for the microcontroller assistant (MCA) and the I/O expander
  - TTL serial console
- Multimedia:
  - Parallel 24-bit LCD interface with FFC on-board connector
  - LVDS interface with up to four differential data pairs
  - 8-bit parallel camera interface

- Audio CODEC with a stereo headphone jack and expansion connectors for speakers, line-in, mic-in, and line-out lines
- Storage:
  - NAND flash
  - microSD card slot
  - 4 GBytes eMMC
- Communication:
  - Two 10/100 Mbps Ethernet interface
  - Two USB Host 2.0 interfaces through a stacked USB A type connector
  - USB OTG with micro AB USB connector
  - SISO IEEE 802.11 a/b/g/n/ac + Bluetooth 4.2 dual mode with on-board U.FL or external MMCX antenna connector
  - PCI Express Mini Card slot supporting full and half-size cards
  - 2 KBytes NFC NTAG
- Expansion:
  - USB Host 2.0 port
  - CAN connector with two FlexCAN interfaces including transceivers
  - UART connector with one TTL level UART and two RS-232 UART ports
  - SPI
  - Audio connector with MIC, LINE-IN, and LINE-OUT
  - Audio connector with speakers and LINE-IN
  - GPIO connector with analog input for touch and digital GPIO signals
  - I2C
- User interface:
  - One user LED
- I/O expander: to allow advanced power-management functionality over the carrier board
- Dimensions:
  - Pico-ITX form factor, 10 cm x 7.2 cm
  - PCB height 2 mm
  - Maximum part height:
    - TOP side: 15.6 mm (USB connector)
    - BOTTOM side: 6.8 mm (PCIe connector) (Host PCBs must have a cutout to accommodate the components on the bottom side of the module.)


# Block diagram






## Placement

### Top view




## Bottom view




# Connectors

## Top view



### Bottom view



### Part numbers

The following table lists manufacturers and part numbers for each connector.

| Connector | Interface        | Manufacturer | Manufacturer part number      |
|-----------|------------------|--------------|-------------------------------|
| J1        | 5V power-in jack | SHOGYO       | MJ-179LR                      |
| J2        | Coin cell        | Molex        | 53047-0210                    |
| J3        | Power and reset  | Molex        | 53047-0310                    |
| J4        | 3.3V output      | Molex        | 53047-0210                    |
| J5        | 5V output        | Molex        | 53047-0210                    |
| J6        | Ethernet 1       | Xmultiple    | XMG-9799-8821-100D-L1TO-H-HIM |
| J7        | microSD          | Molex        | 500873-0806                   |

| Connector | Interface   | Manufacturer    | Manufacturer part number      |
|-----------|---|-----------------|-------------------------------|
| J8        | Ethernet 2  | Xmultiple       | XMG-9799-8821-100D-L1TO-H-HIM |
| J9        | Console   | Molex           | 53047-0410                    |
| J10       | Boot mode   | Samtec          | TSW-102-07-G-S                |
| J12       | Mini PCIe   | Foxconn         | AS0B226-S68Q-7H               |
| J14       | Micro SIM   | Molex           | 78727-0001                    |
| J15       | USB Host  | KYCON           | KUSBX-AS2N                    |
| J16       | USB OTG   | KYCON           | KMMX-ABSMT5SG-30TR            |
| J17       | Parallel camera                                     | OMRON           | XF2M-2015-1A                  |
| J18       | Antenna   | Amphenol        | 908-22101                     |
| J21       | Parallel display                                    | OMRON           | XF2M-4015-1A                  |
| J22       | Audio jack  | CUI Inc.        | SJ1-3515-SMT                  |
| J23-J24   | XBee module   | Samtec          | SMM-110-02-F-S-P-TR           |
| J25       | XBee expansion                                      | Molex           | 53047-0310                    |
| J26       | Audio expansion - line in, line out, and microphone | Molex           | 53047-0810                    |
| J27       | CAN expansion                                       | Molex           | 53047-0610                    |
| J28       | I2C expansion                                       | Molex           | 53047-0610                    |
| J29       | UART expansion                                      | Molex           | 53047-1410                    |
| J30       | GPIO expansion                                      | Molex           | 53047-1410                    |
| J31       | LVDS  | Hirose          | DF14A-20P-1.25H               |
| J32       | USB expansion                                       | Molex           | 53047-0610                    |
| J33       | Audio expansion - speaker and line in               | Molex           | 53047-0610                    |
| J34       | SPI expansion                                       | Molex           | 53047-0810                    |
| J35       | 5V power in   | TE Connectivity | 640456-2                      |
| J36       | NFC NTAG  | Molex           | 53047-0210                    |
| SW1       | Power button  | ITT             | KSC221JLFS                    |
| SW2       | Reset button  | ITT             | KSC221JLFS                    |

| Connector | Interface   | Manufacturer   | Manufacturer part number |
|-----------|---|----------------|--------------------------|
| SW4       | RF kill & RF antenna internal/external selection switch | C&K Components | TDA02H0SB1               |
| CAD1      | i.MX6UL JTAG Tag Connect                                | -              | -                        |
| CAD2      | MCA SWD Tag Connect                                     | -              | -                        |
| CAD3      | IO expander SWD Tag Connect                             | -              | -                        |

## ConnectCore 6UL SBC Pro interfaces

---

|                                       |    |
|---------------------------------------|----|
| Power interfaces .....                | 16 |
| System boot interfaces .....          | 17 |
| Debug interfaces .....                | 19 |
| Communication interfaces .....        | 20 |
| Multimedia interfaces .....           | 28 |
| Storage interfaces .....              | 34 |
| Additional expansion interfaces ..... | 35 |
| User interfaces .....                 | 43 |

## Power interfaces

### DC-in jack connector

A 5V DC-in power jack connector provides power to the entire ConnectCore 6UL SBC Pro system. An overvoltage circuit protects the SBC from voltages higher than 6.5V (up to 12V). Behind the overvoltage protection, a 5V load switch (U7) controls the power delivered to the SBC. The enable pin of the power switch is controlled through PWR\_EN/IO14 signal of the I/O expander. A green LED on the top of the board lights up when the 5V output of the load switch is enabled.

### Additional power connector

In addition to the power jack assembled on the SBC Pro, a 2-pin, 2.54 mm pitch, latched vertical connector on the top side of the PCB offers an alternative power rail to the whole system. This power input is also protected against overvoltage events.

The following table shows the pinout of the power connector (J35):

| Pin | Signal name | Description          |
|-----|-------------|----------------------|
| 1   | VIN         | 5V power supply rail |
| 2   | GND         | Ground               |

---

**Note** Definition of pin 1 in SBC Pro design for J35 (MFG PN: 6440456-2) is reversed from manufacturer datasheet.

---

### Coin cell connector

A 2-pin, 1.25 mm pitch straight connector provides battery charging functionality and powers the real-time-clock (RTC) interface when the main supply is off. The main power supply rail powers the RTC while it is connected. You can supply the RTC with a primary Lithium cell (non-rechargeable), a secondary Lithium cell (rechargeable), or a supercap.

---

**Note** For more information about the coin cell, see [Electrical specification](#).

---

The following table shows the pinout of the coin cell connector (J2):

| Pin | Signal name | Description          |
|-----|-------------|----------------------|
| 1   | VCC_LICELL  | Power supply for RTC |
| 2   | GND         | Ground               |

### Power and reset buttons

The power button (SW1) on the ConnectCore 6UL SBC Pro is connected to the on-module MCA, which provides the following functionality:



| Board status | Power button action      | Response  |
|--------------|--------------------------|-----------|
| OFF          | Short press              | Power on  |
| ON or SLEEP  | Long press for 5 seconds | Power off |
| SLEEP        | Short press              | Wake-up   |
| ON           | Short press              | Sleep     |

The ConnectCore 6UL SBC Pro also has a "Reset" button (SW2), which resets the ConnectCore 6UL module.

---

**Note** You can configure the duration of some power button actions. See the [device tree bindings for the MCA power key driver](#) for more information.

---

## 5V supply connector

The ConnectCore 6UL SBC Pro provides a 2-pin, 1.25 mm pitch straight connector with a regulated 5V supply for powering external circuitry. The 5V supply is generated on the on-board 5V regulator, which is also used internally in the ConnectCore 6UL SBC for powering interfaces such as the displays (LCD and LVDS) and the USB VBUS. The following table shows the pinout of the 5V supply connector (J5).

| Pin | Signal name | Description   |
|-----|-------------|---------------|
| 1   | 5V          | 5V power line |
| 2   | GND         |               |

## 3.3V supply connector

The ConnectCore 6UL SBC Pro provides a 2-pin, 1.25 mm pitch straight connector with a regulated 3.3V supply for powering external circuitry. The 3.3V supply is generated on a buck regulator of the ConnectCore 6UL PMIC (3V3\_EXT power domain), which is also used on-board for powering many interfaces of the ConnectCore 6UL SBC carrier board. The following table shows the pinout of the 3.3V supply connector (J4).

| Pin | Signal name | Description     |
|-----|-------------|-----------------|
| 1   | 3V3         | 3.3V power line |
| 2   | GND         |                 |

# System boot interfaces

## Boot configuration

The ConnectCore 6UL SBC Pro has several 10 K resistors to allow for maximum flexibility when setting up the boot source configuration of the ConnectCore 6UL module. The following table provides detailed information about resistor configuration.

---

**Note** Default configuration is shown in bold.

---

| BOOT_CFG bit (pad)       | Resistor configuration |             |
|--------------------------|------------------------|-------------|
|                          | Pull-up                | Pull-down   |
| BOOT_CFG1[0] (LCD_DATA0) | R222                   | <b>R112</b> |
| BOOT_CFG1[1] (LCD_DATA1) | R233                   | <b>R113</b> |
| BOOT_CFG1[2] (LCD_DATA2) | R234                   | <b>R147</b> |
| BOOT_CFG1[3] (LCD_DATA3) | R235                   | <b>R153</b> |
| BOOT_CFG1[4] (LCD_DATA4) | <b>R17</b>             | R238        |
| BOOT_CFG1[5] (LCD_DATA5) | R236                   | <b>R156</b> |
| BOOT_CFG1[6] (LCD_DATA6) | R237                   | <b>R166</b> |
| BOOT_CFG1[7] (LCD_DATA7) | <b>R100</b>            | R239        |

| BOOTSTRAP    | NAND  |
|--------------|---|
| BOOT_CFG1[0] | Row address cycles:<br><b>00 - 3 cycles</b><br>01 - 2 cycles<br>10 - 4 cycles<br>11 - 5 cycles  |
| BOOT_CFG1[1] |   |
| BOOT_CFG1[2] | Number of devices:<br><b>00 - 1 device</b><br>01 - 2 devices<br>10 - 4 devices<br>11 - Reserved |
| BOOT_CFG1[3] |   |
| BOOT_CFG1[4] | Pages in block:<br>00 - 128 pages<br><b>01 - 64 pages</b><br>10 - 32 pages<br>11 - 256 pages    |
| BOOT_CFG1[5] |   |
| BOOT_CFG1[6] | Samsung toggle mode DDR NAND:<br><b>0 - Raw NAND</b><br>1 - Toggle mode NAND                    |
| BOOT_CFG1[7] | Boot device selection:<br><b>1 - Boot from NAND interface</b>                                   |

**Note** Bootstrap pins are protected against being overwritten by devices connected to the LCD signals. See the [ConnectCore 6UL SBC Pro schematics \(PDF\)](#) for circuitry around U30 and U31.

## Boot mode

By default, the ConnectCore 6UL module boots from the internal board settings, allowing it to boot from internal NAND memory. However, it is possible to boot from USB through a jumper (J10). This jumper forces the i.MX6UL to boot from the source programmed in the one-time-programmable (OTP)

bits. If the boot configuration OTP bits are not programmed, the CPU falls back to booting into USB debug mode.

The default state for the jumper is open, which configures the i.MX6UL to boot from board settings (from NAND flash). If the NAND flash doesn't contain valid firmware, the i.MX6UL also falls back to booting into USB debug mode. You can use this functionality for recovery purposes, such as if the boot loader is erased or cannot boot.

For advanced functionality, the ConnectCore 6UL SBC Pro provides four resistors to configure the SOM boot mode. For more information about boot mode configuration, please refer to the [ConnectCore for i.MX6UL system-on-module Hardware Reference Manual](#).

The following table shows resistor configuration for the different boot modes:

| R24           | R25           | R28           | R29           | Comment                            |
|---------------|---------------|---------------|---------------|------------------------------------|
| Not populated | Not populated | Populated     | Populated     | Boot from fuses                    |
| Populated     | Not populated | Not populated | Populated     | Boot from serial downloader        |
| Not populated | Populated     | Populated     | Not populated | Boot from board settings (default) |
| Populated     | Populated     | Not populated | Not populated | Reserved                           |

**Note** A different resistor configuration may prevent the ConnectCore 6UL module from booting.

## Debug interfaces

### JTAG

The ConnectCore 6UL SBC Pro provides a Tag Connect footprint for accessing the i.MX6UL JTAG debug port. You can find this footprint on the bottom side of the board.

### SWD

The ConnectCore 6UL SBC Pro provides two options for programming and debugging the MCA of the ConnectCore 6UL module. The first option is a 2x5, 1.27 mm pitch pin header on the top side of the board (which, by default, is not populated). The following table shows the pinout of the SWD connector.

| Pin | Signal name | Description                    |
|-----|-------------|--------------------------------|
| 1   | VCC_MCA     | 3.3V supply voltage of the MCA |
| 2   | MCA_SWD_DIO | SWD bidirectional data pin     |
| 3   | GND         | Ground                         |
| 4   | MCA_SWD_CLK | SWD clock signal               |
| 5   | VCC_MCA     | 3.3V supply voltage of the MCA |
| 6   | NC          | Not connected                  |
| 7   | NC          | Not connected                  |

| Pin | Signal name | Description          |
|-----|-------------|----------------------|
| 8   | NC          | Not connected        |
| 9   | GND         | Ground               |
| 10  | MCA_RESET_N | Reset signal for MCA |

The second option is the Tag Connect footprint on the bottom side of the board.

You can also access the SWD interface of the I/O expander using options similar to those found on the on-module MCA: a non-populated 2x5, 1.27 mm pitch pin header and a Tag Connect footprint.

## Console port

The ConnectCore 6UL SBC Pro provides a 4-pin, 1.25 pitch connector for the debug console port. The UART5 port of the ConnectCore 6UL module is used as the console port. The console signal is a serial TTL, which travels through the console connector directly to the i.MX6UL processor. You can use a TTL-to-USB cable to access this console port from a host PC USB port. The following table shows the pinout of the console connector (J9):

| Pin | Signal name | Description       |
|-----|-------------|-------------------|
| 1   | UART5_TX    | Transmission line |
| 2   | UART5_RX    | Receiver line     |
| 3   | 3V3         | 3.3V power line   |
| 4   | GND         | Ground            |



**CAUTION!** Pin 3 - 3V3 is a power output of the SBC. It should not be connected to a power input coming from the USB to TTL cable, for instance.

Console default settings:

|                     |        |
|---------------------|--------|
| <b>Baud rate</b>    | 115200 |
| <b>Data</b>         | 8 bit  |
| <b>Parity</b>       | none   |
| <b>Stop</b>         | 1 bit  |
| <b>Flow control</b> | none   |

## Communication interfaces

### NFC NTAG

A 2KB (2016 bytes of EEPROM and 64 bytes of SRAM) NTAG is carried by the ConnectCore 6UL SBC Pro. This NTAG is an energy-harvesting NFC Forum type 2 Tag with field detection and I2C interface. The RF interface is based on the ISO/IEC 14443 Type A standard. This RF interface is passive and must be supplied by an RF field.

The SBC has an antenna connector (36) for the NTAG:

| Pin | Signal name | Description           |
|-----|-------------|-----------------------|
| 1   | LA          | Antenna connection LA |
| 2   | LB          | Antenna connection LB |

**Note** For more information on this interface, please contact Digi technical support at [www.digi.com/support](http://www.digi.com/support).

## 10/100 Mbps Ethernet

The ConnectCore 6UL SBC Pro provides two 10Base-T/100Base-Tx Ethernet interfaces using two Microchip LAN8720Ai 10/100 Ethernet PHYs. The Ethernet PHYs are connected to the i.MX6UL ENET1 and ENET2 instances, respectively. Both Ethernet interfaces are accessible through RJ-45 connectors with integrated link/activity LEDs. The following table shows the pinout of both RJ45 connectors.

| Pin | Signal name | Description            |
|-----|-------------|------------------------|
| 1   | TD+         | Transmit pair data (+) |
| 2   | TD-         | Transmit pair data (-) |
| 3   | RD+         | Receive pair data (+)  |
| 4   | CT          | Center tap             |
| 5   | CT          | Center tap             |
| 6   | RD-         | Receive pair data (-)  |
| 7   | NC          | Not connected          |
| 8   | GND         | Ground                 |
| 9   | LED1_P      | Green LED anode        |
| 10  | LED1_N      | Green LED cathode      |
| 11  | LED2_P      | Yellow LED anode       |
| 12  | LED2_N      | Yellow LED cathode     |

The 10/100 Ethernet PHYs have two outputs to indicate the link and activity status of the port. These outputs are connected to two LEDs that are integrated with the Ethernet connectors. The following table shows the link/activity status indicated by the two LEDs:

| Green LED | Yellow LED | Link/activity status |
|-----------|------------|----------------------|
| OFF       | OFF        | Link OFF             |
| ON        | OFF        | 10 Link/no activity  |

| Green LED | Yellow LED | Link/activity status |
|-----------|------------|----------------------|
| Blinking  | OFF        | 10 Link/activity     |
| ON        | ON         | 100 Link/no activity |
| Blinking  | ON         | 100 Link/activity    |

### Ethernet PHY on/off


You can control Ethernet PHY power supply through a power switch to improve system power management. ENET\_PWR/IO26 signal from the I/O expander controls the state of the power switch.

**Note** The PHYs share the same power switch, so they will always be switched on or off together.

### Antenna connector

The ConnectCore 6UL SBC Pro includes an MMCX jack connector to support the wireless and Bluetooth functionality available in the ConnectCore 6UL module. The connector for this antenna is placed on the top-right side of the board.

**Note** The double switch SW4 selects between the on-module antenna and the SBC antenna, so they cannot be used simultaneously. The upper switch (1) selects the antenna (see picture below).



See the [Regulatory Information and Certifications](#) section of the ConnectCore 6UL module Hardware Reference Manual for a list of certificated antennas for the ConnectCore 6UL module.

This double switch SW4 also controls one of the RF kill signals: RF\_KILL\_HW#. Either this RF\_KILL\_HW# or the internal RF\_KILL\_SW# (connected to the I/O expander RF\_KILL\_SW#/IO2 signal) must be triggered to generate an RF kill event.



**CAUTION!** The signals WLAN\_RF\_KILL#, BT\_RF\_KILL#, WLAN LED and BTLED are not yet supported by the wireless baseband chip. Please contact Digi technical support at [www.digi.com/support](http://www.digi.com/support) before using these features.

## USB Host

The ConnectCore 6UL SBC Pro offers support for four USB Host interfaces. Two of them are available over a stackable dual USB A-type connector located on the front of the board. The third USB Host is connected to the PCI Express Mini card connector. The fourth is available on a 6-pin, 1.25 mm pitch expansion connector. All USB Hosts can operate at full, high, and low speed.

The following table shows the pinout of the dual stackable USB Host connector:

| Pin | Signal name | Description                        |
|-----|-------------|------------------------------------|
| 1   | VIN         | 5V power line                      |
| 2   | USBH1_D_N   | USB 1 differential data signal (-) |
| 3   | USBH1_D_P   | USB 1 differential data signal (+) |
| 4   | GND         | Ground                             |
| 5   | VIN         | 5V power line                      |
| 6   | USBH2_D_N   | USB 2 differential data signal (-) |
| 7   | USBH2_D_P   | USB 2 differential data signal (+) |
| 8   | GND         | Ground                             |

The following table shows the pinout of the USB expansion connector:

| Pin | Signal name  | Description                        |
|-----|--------------|------------------------------------|
| 1   | VIN          | 5V power line                      |
| 2   | USBH4_D_P    | USB 4 differential data signal (+) |
| 3   | USBH4_D_N    | USB 4 differential data signal (-) |
| 4   | USBH4_OC_N   | Over current input                 |
| 5   | USBH4_PWR_EN | Power enable output                |
| 6   | GND          | Ground                             |

The USB hub can be switched off for advanced power management through the USB\_PWR/IO21 signal from the I/O expander.

## USB OTG

A micro-AB type receptacle for USB OTG connection is available on the bottom side of the ConnectCore 6UL SBC Pro. This interface can operate in both Host and Device mode.

High-speed, full-speed, and low-speed connections are supported in Host mode. High-speed and full-speed connections are supported in Device mode.

When the interface is configured as Host mode, a 5V power supply line is connected to pin 1 (VBUS) of the USB OTG connector. In Device mode, this line is opened. The following table shows the pinout of the USB OTG connector:

| Pin | Signal name  | Description                                       |
|-----|--------------|---|
| 1   | USB_OTG_VBUS | 5V power line                                     |
| 2   | USB_OTG_D_N  | USB differential data signal (-)                  |
| 3   | USB_OTG_D_P  | USB differential data signal (+)                  |
| 4   | USB_OTG_ID   | Connected to GND for Host and floating for Device |
| 5   | GND          | Ground  |

## Mini PCI Express slot

The ConnectCore 6UL SBC Pro provides a Mini PCI Express connector with the following interfaces:

- I2C
- USB Host port (USBH3)
- GPIO signal (I/O expander PCIE\_WAKE\_N/IO38 signal) for the open drain, low-level PCIe wake up signal
- GPIO signal (I/O expander PCIE\_DIS\_N/IO12 signal) for the low-level PCIe disable signal
- SIM interface
- +3.3V supply

The PCIe interface has a dedicated 3.3V regulator. For power consumption management, this regulator can be controlled through I/O expander PCIE\_VCC\_EN/IO27 signal.

The ConnectCore 6UL SBC Pro has four 2.6 mm metalized drills: two for the half-size and two for the full-size mechanization. These drills have a 5.8 mm x 5.8 mm area without parts or routes for the screws and nuts. To install a PCI Express mini card on the ConnectCore 6UL SBC Pro, you need two M2.5 nuts, two M2.5 screws, two 4 mm M2.5 spacers, and two M2.5 washers.

The following table shows the pinout of the PCI Express Mini card connector:



| Pin | Signal name   | Description                      |
|-----|---------------|----------------------------------|
| 1   | PCIE_WAKE_N   | Wake-up signal                   |
| 2   | PCIE_VCC      | 3.3V power line                  |
| 3   | NC            | Not connected                    |
| 4   | GND           | Ground                           |
| 5   | NC            | Not connected                    |
| 6   | NC            | Not connected                    |
| 7   | NC            | Not connected                    |
| 8   | PCIE_UIM_PWR  | Power supply for SIM card        |
| 9   | GND           | Ground                           |
| 10  | PCIE_UIM_DATA | SIM card data line               |
| 11  | NC            | Not connected                    |
| 12  | PCIE_UIM_CLK  | SIM card clock line              |
| 13  | NC            | Not connected                    |
| 14  | PCIE_UIM_RST  | SIM card reset line              |
| 15  | GND           | Ground                           |
| 16  | PCIE_UIM_VPP  | Power supply for SIM programming |
| 17  | NC            | Not connected                    |
| 18  | GND           | Ground                           |
| 19  | NC            | Not connected                    |
| 20  | PCIE_DIS_N    | Disable signal                   |
| 21  | GND           | Ground                           |
| 22  | NC            | Not connected                    |
| 23  | NC            | Not connected                    |
| 24  | PCIE_VCC      | 3.3V power line                  |
| 25  | NC            | Not connected                    |
| 26  | GND           | Ground                           |
| 27  | GND           | Ground                           |
| 28  | NC            | Not connected                    |
| 29  | GND           | Ground                           |

| Pin | Signal name  | Description                        |
|-----|--------------|------------------------------------|
| 30  | PCIE_I2C_SCL | i.MX6UL I2C1 bus clock line        |
| 31  | NC           | Not connected                      |
| 32  | PCIE_I2C_SDA | i.MX6UL I2C1 bus data line         |
| 33  | NC           | Not connected                      |
| 34  | GND          | Ground                             |
| 35  | GND          | Ground                             |
| 36  | USBH3_D_N    | USB 3 differential data signal (-) |
| 37  | GND          | Ground                             |
| 38  | USBH3_D_P    | USB 3 differential data signal (+) |
| 39  | PCie_VCC     | 3.3V power line                    |
| 40  | GND          | Ground                             |
| 41  | PCie_VCC     | 3.3V power line                    |
| 42  | NC           | Not connected                      |
| 43  | GND          | Ground                             |
| 44  | NC           | Not connected                      |
| 45  | NC           | Not connected                      |
| 46  | NC           | Not connected                      |
| 47  | NC           | Not connected                      |
| 48  | NC           | Not connected                      |
| 49  | NC           | Not connected                      |
| 50  | GND          | Ground                             |
| 51  | NC           | Not connected                      |
| 52  | PCie_VCC     | 3.3V power line                    |

### Micro-SIM

A micro-SIM card slot is located on the bottom side of the board. The SIM interface is connected to the PCIe Mini card connector, enabling cellular communication when a modem is installed in the Mini Card connector.

The following table shows the SIM card slot pinout:

| Pin | Signal name  | Description       |
|-----|--------------|-------------------|
| 1   | PCIE_UIM_PWR | Power supply line |

| Pin | Signal name   | Description                      |
|-----|---------------|----------------------------------|
| 2   | PCIE_UIM_RST  | SIM card reset line              |
| 3   | PCIE_UIM_CLK  | SIM card clock line              |
| 4   | NC            | Not connected                    |
| 5   | GND           | Ground                           |
| 6   | PCIE_UIM_VPP  | Power supply for SIM programming |
| 7   | PCIE_UIM_DATA | SIM card data line               |
| 8   | NC            | Not connected                    |

## XBee

The ConnectCore 6UL SBC Pro provides two 10-pin, 2 mm pitch connectors to connect a Digi XBee/XBee-PRO module. The XBee identification and association signals are connected to a 3-pin, 1.25 mm pitch expansion connector.

The XBee module communicates with the ConnectCore 6UL through the UART2 port. This UART2 port is also available on the UART expansion connector to allow for other uses besides the XBee interface. Four GPIO signals of the ConnectCore 6UL reset the XBee and control the status of the XBee module. The table below shows the pinout of the XBee module connectors (J23 and J24):

| Pin | Signal name     | Description  |
|-----|-----------------|--|
| 1   | XBEE_VCC        | 3.3V power line  |
| 2   | UART2_RX        | XBee output data line  |
| 3   | UART2_TX        | XBee input data line   |
| 4   | NC              | Not connected  |
| 5   | XBEE_RESET_N    | XBee reset line (connected to I/O expander XBEE_RSTN/IO7 signal)       |
| 6   | NC              | Not connected  |
| 7   | NC              | Not connected  |
| 8   | NC              | Not connected  |
| 9   | XBEE_SLEEP_RQ   | XBee request line (connected to I/O expander XBEE_SLP_RQ/IO9 signal)   |
| 10  | GND             | Ground   |
| 11  | NC              | Not connected  |
| 12  | UART2_RTS_N     | XBee request to send   |
| 13  | XBEE_ON/SLEEP_N | XBee status line (connected to I/O expander XBEE_ON/SLP_N/IO11 signal) |
| 14  | NC              | Not connected  |

| Pin | Signal name | Description  |
|-----|-------------|--|
| 15  | XBEE_ASSOC  | XBee associated line   |
| 16  | UART2_CTS_N | XBee clear to send line  |
| 17  | NC          | Not connected  |
| 18  | NC          | Not connected  |
| 19  | NC          | Not connected  |
| 20  | XBEE_IDENT  | XBee commissioning line (connected to I/O expander XBEE_IDENT/IO33 signal) |

The following table shows the pinout of the XBee expansion connector (J22):

| Pin | Signal name | Description             |
|-----|-------------|-------------------------|
| 1   | XBEE_IDENT  | XBee commissioning line |
| 2   | XBEE_ASSOC  | XBee associated line    |
| 3   | GND         | Ground                  |



**CAUTION!** The XBee socket is powered through an external DC/DC regulator (U23 - MP2316). The purpose of this external regulator is to provide higher current than using 3V3 supply coming from the module. **Disabling this regulator doesn't guarantee that the XBee socket is fully disconnected from the module.** In fact, some current travels through the I/Os to the module even after the regulator is disabled.

If your design requires fully disconnecting the XBee socket from the ConnectCore 6UL module, Digi recommends you use bus switches for all I/Os connected to the XBee socket.

## Multimedia interfaces

### Parallel display

The ConnectCore 6UL provides a 24-bit RGB LCD interface available on the top side of the board through a 40-pin, 0.5 mm pitch, FFC connector. Backlight control signal, I2C port, and interrupt line for the touch screen panel are available on the LCD connector. This connector also provides a 3.3V power line for the LCD display and a 5V power line for the LED backlight.

By default, only data lines 0 to 17 are connected, allowing an 18-bit parallel video interface. Data lines 18 to 23 can be connected through 0-ohm resistors that, by default, are not populated.

The 5V power supply is controlled through I/O expander DISP\_5V\_PWR/IO29 signal.

The following table shows the pinout of the parallel display connector (J21):

| Pin | Signal name          | Description                                      | 16-bit | 18-bit | 24-bit |
|-----|----------------------|--|--------|--------|--------|
| 1   | GND                  | Ground   |        |        |        |
| 2   | LCD_DATA0            | Display data line 0                              | B[0]   | B[0]   | B[0]   |
| 3   | LCD_DATA1            | Display data line 1                              | B[1]   | B[1]   | B[1]   |
| 4   | LCD_DATA2            | Display data line 2                              | B[2]   | B[2]   | B[2]   |
| 5   | LCD_DATA3            | Display data line 3                              | B[3]   | B[3]   | B[3]   |
| 6   | LCD_DATA4            | Display data line 4                              | B[4]   | B[4]   | B[4]   |
| 7   | LCD_DATA5            | Display data line 5                              | G[0]   | B[5]   | B[5]   |
| 8   | LCD_DATA6            | Display data line 6                              | G[1]   | G[0]   | B[6]   |
| 9   | LCD_DATA7            | Display data line 7                              | G[2]   | G[1]   | B[7]   |
| 10  | LCD_DATA8            | Display data line 8                              | G[3]   | G[2]   | G[0]   |
| 11  | LCD_DATA9            | Display data line 9                              | G[4]   | G[3]   | G[1]   |
| 12  | LCD_DATA10           | Display data line 10                             | G[5]   | G[4]   | G[2]   |
| 13  | LCD_DATA11           | Display data line 11                             | R[0]   | G[5]   | G[3]   |
| 14  | LCD_DATA12           | Display data line 12                             | R[1]   | R[0]   | G[4]   |
| 15  | LCD_DATA13           | Display data line 13                             | R[2]   | R[1]   | G[5]   |
| 16  | LCD_DATA14           | Display data line 14                             | R[3]   | R[2]   | G[6]   |
| 17  | LCD_DATA15           | Display data line 15                             | R[4]   | R[3]   | G[7]   |
| 18  | LCD_DATA16           | Display data line 16                             |        | R[4]   | R[0]   |
| 19  | LCD_DATA17           | Display data line 17                             |        | R[5]   | R[1]   |
| 20  | LCD_DATA18           | Display data line 18 (NC, serial resistor: R41)  |        | -      | R[2]   |
| 21  | LCD_DATA19           | Display data line 19 (NC, serial resistor: R207) |        | -      | R[3]   |
| 22  | LCD_DATA20/SPI1_CLK  | Display data line 20 (NC, serial resistor: R208) |        | -      | R[4]   |
| 23  | LCD_DATA21/SPI1_SS0  | Display data line 21 (NC, serial resistor: R209) |        | -      | R[5]   |
| 24  | LCD_DATA22/SPI1_MOSI | Display data line 22 (NC, serial resistor: R210) |        | -      | R[6]   |
| 25  | LCD_DATA23/SPI1_MISO | Display data line 23 (NC, serial resistor: R211) |        | -      | R[7]   |

| Pin | Signal name   | Description   | 16-bit | 18-bit | 24-bit |
|-----|---------------|---|--------|--------|--------|
| 26  | GND           | Ground  |        |        |        |
| 27  | DISP0_CLK     | Display clock line  |        |        |        |
| 28  | GND           | Ground  |        |        |        |
| 29  | DISP0_HSYNC   | Horizontal sync line  |        |        |        |
| 30  | DISP0_VSYNC   | Vertical sync line  |        |        |        |
| 31  | DISP0_DRDY    |   |        |        |        |
| 32  | DISP0_RESET   |   |        |        |        |
| 33  | DISP0_I2C_SCL | i.MX6UL I2C1 bus clock line   |        |        |        |
| 34  | DISP0_I2C_SDA | i.MX6UL I2C1 bus data line  |        |        |        |
| 35  | DISP0_IRQ_N   | Interrupt line (connected to i.MX6UL GPIO5_IO02) with a 10K pull-up |        |        |        |
| 36  | GND           | Ground  |        |        |        |
| 37  | BCKL_PWM      | Backlight PWM (connected to i.MX6UL NAND_DQS)                       |        |        |        |
| 38  | 3V3           | 3.3V power line   |        |        |        |
| 39  | 5V_DISPLAY    | 5V power line   |        |        |        |
| 40  | 5V_DISPLAY    | 5V power line   |        |        |        |

**Note** 24-bit displays can be connected to an 18-bit parallel LCD bus. For this, the six most significant data bits of the display are connected to the 18-bit LCD bus. The remaining two least significant data bits of the display can be connected in two ways:

- Connected either to GND or VCC. In this case, it's not possible to reach a full black or white.
- Connected to the lower bits of the same color. In this case, full black and white can be reached, but some color gradients are lost.

## LVDS

The ConnectCore 6UL SBC Pro provides an LVDS interface from a parallel-to-LVDS transceiver. The LVDS connector is on the bottom side of the board, close to the LCD connector.

**Pad conflicts**

*The LVDS and parallel connectors share the same video interface and therefore cannot be used simultaneously.*

This LVDS connector provides access to the following LVDS capabilities:

- Up to four LVDS differential data pairs
- One LVDS differential clock pair
- Interrupt signal with 10K pull-up resistor for touch screen (shared with parallel display interface)
- Control of the backlight contrast (shared with parallel display interface)
- I2C (shared with parallel display interface)
- 3.3V power supply for the LCD
- 5V power supply for the LED backlight (shared with parallel display interface)

The LVDS interface is available in a 20-pin, 1.25 mm pitch Hirose DF14 connector (J31). The following table shows the pinout:

| Pin | Signal name   | Description                                    |
|-----|---------------|--|
| 1   | 3V3           | 3.3V power line                                |
| 2   | LVDS0_TX0_N   | Transmission pair data line 0 (-)              |
| 3   | LVDS0_TX0_P   | Transmission pair data line0 (+)               |
| 4   | GND           | Ground   |
| 5   | LVDS0_TX1_N   | Transmission pair data line 1 (-)              |
| 6   | LVDS0_TX1_P   | Transmission pair data line 1 (+)              |
| 7   | GND           | Ground   |
| 8   | LVDS0_TX2_N   | Transmission pair data line 2 (-)              |
| 9   | LVDS0_TX2_P   | Transmission pair data line 2 (+)              |
| 10  | GND           | Ground   |
| 11  | LVDS0_CLK_N   | Transmission pair clock line (-)               |
| 12  | LVDS0_CLK_P   | Transmission pair clock line (+)               |
| 13  | GND           | Ground   |
| 14  | LVDS0_TX3_N   | Transmission pair data line 3 (-)              |
| 15  | LVDS0_TX3_P   | Transmission pair data line 3 (+)              |
| 16  | BCKL_PWM      | Backlight PWM (connected to i.MX6UL NAND_DQS)  |
| 17  | DISP0_I2C_SCL | i.MX6UL I2C1 bus clock line                    |
| 18  | DISP0_I2C_SDA | i.MX6UL I2C1 bus data line                     |
| 19  | DISP0_IRQ_N   | Interrupt line (connected to i.MX6UL GPIO5_09) |
| 20  | 5V_DISPLAY    | 5V power line                                  |

You can switch off the parallel-to-LVDS transceiver for advanced power management through I/O expander LVDS\_PD#/IO30 signal.

## Parallel camera

The ConnectCore 6UL SBC Pro provides a parallel camera sensor interface (CSI), which is located on the top side of the board. This camera interface is composed of an 8-bit data line bus, a master clock, and three synchronization signals (PIXCLK, HSYNC, and VSYNC).

This parallel camera interface is available in a 20-pin, 0.5 mm pitch FFC connector (J17). The pinout is shown in the following table:

| Pin | Signal name   | Description  |
|-----|---------------|--|
| 1   | GND           | Ground   |
| 2   | CSI_DATA02    | Camera data line 0   |
| 3   | CSI_DATA03    | Camera data line 1   |
| 4   | CSI_DATA04    | Camera data line 2   |
| 5   | CSI_DATA05    | Camera data line 3   |
| 6   | CSI_DATA06    | Camera data line 4   |
| 7   | CSI_DATA07    | Camera data line 5   |
| 8   | CSI_DATA08    | Camera data line 6   |
| 9   | CSI_DATA09    | Camera data line 7   |
| 10  | GND           | Ground   |
| 11  | CSI_MCLK      | Camera master clock line   |
| 12  | CSI_PIXCLK    | Camera pixel clock line  |
| 13  | CSI_HSYNC     | Camera horizontal sync   |
| 14  | CSI_VSYNC     | Camera vertical sync   |
| 15  | CSI_GPIO/IO31 | Connected to I/O expander CSI0_GPIO/IO31 signal                  |
| 16  | CSI_PWDN/IO22 | Camera power down line (connected to I/O expander CSI_PWDN/IO22) |
| 17  | GND           | Ground   |
| 18  | CSI_I2C_SCL   | i.MX6UL I2C1 bus clock line                                      |
| 19  | CSI_I2C_SDA   | i.MX6UL I2C1 bus data line                                       |
| 20  | 3V3           | 3.3V power line  |

### Pad conflicts

*The data lines of the camera interface are shared with the eMMC and microSD interfaces, so the camera cannot be used simultaneously with these interfaces.*

## Audio

Audio functionality on the ConnectCore 6UL SBC Pro provides headphone, speaker, line-out, two line-in, and microphone signals. A Maxim MAX98089 audio codec manages the audio interface. You can



configure the audio codec through the i.MX6UL I2C1 bus. For power management, the ConnectCore 6UL SBC Pro provides a switch for powering on and off the audio interface. The switch is controlled with the I/O expander AUD\_PWR/IO28 signal.


The headphone audio output of the audio codec is connected to a stereo audio jack located on the front edge of the SBC. The table below shows the pinout of the audio jack connector:

| Pin | Signal name | Description                |
|-----|-------------|----------------------------|
| 1   | GND         | Ground                     |
| 2   | HPR         | Audio right channel output |
| 3   | HPL         | Audio left channel output  |
| 4   | NC          | Not connected              |
| 5   | NC          | Not connected              |

The line-in, line-out, and microphone audio signals are available through an 8-pin, 1.25 mm pitch expansion connector (J26). The following table shows the pinout of this connector:

| Pin | Signal name | Description                      |
|-----|-------------|----------------------------------|
| 1   | MIC_N       | Microphone input negative signal |
| 2   | MIC_P       | Microphone input positive signal |
| 3   | LINE_IN_A_R | Line-in A right channel signal   |
| 4   | LINE_IN_A_L | Line-in A left channel signal    |
| 5   | GND         | Ground                           |
| 6   | LINE_OUT_R  | Line-out left channel signal     |
| 7   | LINE_OUT_L  | Line-out right channel signal    |
| 8   | GND         | Ground                           |

LINE\_OUT\_R and LINE\_OUT\_L are swapped in the design. LINE\_OUT\_R signal corresponds to left channel and LINE\_OUT\_L to right channel:



The MAX98089 audio codec also allows speakers to be connected to internal Class D amplifiers. An additional line-in input is also available on the audio codec. This additional functionality is available in a 6-pin, 1.25 mm pitch expansion connector (J33). The following table shows the pinout:

| Pin | Signal name | Description                                   |
|-----|-------------|---|
| 1   | SPKL_P      | Positive left-channel Class D speaker output  |
| 2   | SPKL_N      | Negative left-channel Class D speaker output  |
| 3   | SPKR_P      | Positive right-channel Class D speaker output |
| 4   | SPKR_N      | Negative right-channel Class D speaker output |
| 5   | LINE_IN_B_R | Line-in B right channel                       |
| 6   | LINE_IN_B_L | Line-in B left channel                        |

## Storage interfaces

### microSD

A microSD connector is located on the bottom side of the SBC. This interface is connected to the USDHC2 controller of the i.MX6UL CPU.

The following table shows the pinout of the microSD socket:

| Pin | Signal name | Description  |
|-----|-------------|--|
| 1   | CSI_DATA04  | Serial data 2  |
| 2   | CSI_DATA05  | Serial data 3  |
| 3   | SD_CMD      | Command line - output of the analog switch (U33) for CSI0_HSYNC signal |
| 4   | 3V3         | 3.3V power line  |
| 5   | SD_CLK      | Serial clock - output of the analog switch (U34) for CSI0_VSYNC signal |
| 6   | GND         | Ground   |
| 7   | CSI_DATA02  | Serial data 0  |
| 8   | CSI_DATA03  | Serial data 1  |
| 9   | GND         | Ground   |
| 10  | GND         | Ground   |

### eMMC

The ConnectCore 6UL SBC Pro carries a 4 GBytes eMMC memory. This interface is connected to the USDHC2 controller of the i.MX6UL CPU.

#### *Pad conflicts*

*The eMMC shares the connection to the i.MX6UL processor with the microSD interface. The selection is made via the eMMC/SD# signal, which is driven by the i.MX6UL processor, so the devices cannot be used simultaneously.*

The eMMC/SD# signal is connected to the GPIO5\_01 port of the i.MX6UL. The following table describes its behavior:

| eMMC/SD# level | Description       |
|----------------|-------------------|
| Low            | microSD connected |
| High           | eMMC connected    |

The eMMC memory can be switched off for advanced power management through I/O expander eMMC\_PWR/IO8 signal.

## Additional expansion interfaces

### I/O Expander

#### Introduction

The digital I/O Expander is an IC that extends the available GPIOs, ADCs, and IRQ sources available on the ConnectCore 6UL SBC Pro. The I/O Expander and the ConnectCore 6UL module are connected through an I2C interface and two interrupt lines that allow the I/O Expander to request attention from the host (IOEXP\_INT\_MCA# and IOEXP\_INT\_iMX#). However, only IOEXP\_INT\_MCA# is currently used by the firmware.

The I/O Expander provides the following functionalities on the ConnectCore 6UL SBC Pro:

- Ability to control different power domains through GPIOs configured as outputs.
- General purpose I/O, IRQ, and ADCs through user connectors.
- Peripheral control:
  - User LED
  - Parallel camera port reset
  - XBee socket lines.

#### Power domain control

The following table lists the lines that are intended to control the power domains of the peripherals in the ConnectCore 6UL SBC Pro:

| I/O Expander pin name | Signal name     | Pin direction | Description  | Peripheral affected |
|-----------------------|-----------------|---------------|--|---------------------|
| I02                   | RF_KILL_SW#IO2  | Output        | Part of the logic for disabling RF modules. Currently not supported. | CCWi-i.MX6UL        |
| I08                   | eMMC_PWR/IO8    | Output        | Controls the 3V3_eMMC power rail.                                    | eMMC                |
| I012                  | PCIE_DIS_N/IO12 | Output        | Connected to the miniPCIe socket.                                    | miniPCIe socket     |

| I/O Expander pin name | Signal name      | Pin direction | Description   | Peripheral affected                |
|-----------------------|------------------|---------------|---|------------------------------------|
| I014                  | PWR_EN/I014      | Output        | Controls the 5V power supply line for external load.            | 5V regulator and LED.              |
| I015                  | CAN_EN2/I015     | Output        | Enables/disables the CAN2 transceiver. Currently not supported. | CAN2 transceiver                   |
| I017                  | CAN_EN1/I017     | Output        | Enables/disables the CAN1 transceiver. Currently not supported. | CAN1 Transceiver                   |
| I018                  | UART_PWR/I018    | Output        | Controls the RS232-TTL transceiver.                             | UART 1 & UART 3 transceivers       |
| I021                  | USB_PWR/I021     | Output        | Controls the 3V3_USB power rail.                                | USB Host Hub Controller.           |
| I026                  | ENET_PWR/I026    | Output        | Controls the 3V3_ETH power rail.                                | Ethernet PHYs.                     |
| I027                  | PCIE_VCC_EN/I027 | Output        | Controls the PCIe_VCC power rail.                               | miniPCIe socket                    |
| I028                  | AUD_PWR/I028     | Output        | Controls the 3V3_CODEC power rail.                              | Audio codec                        |
| I029                  | DISP_5V_PWR/I029 | Output        | Controls the 5V_Display power rail.                             | LVDS and Parallel display sockets. |
| I030                  | LVDS_PD#/I030    | Output        | Powers down the LVDS transmitter.                               | LVDS Transmitter                   |
| I034                  | CAN_STBY/I034    | Output        | Sets the CAN1 and CAN2 transceiver into low-power standby mode. | CAN1 & CAN2 Transceiver            |
| I038                  | PCIE_WAKE_N/I038 | Output        | Connected to the miniPCIe socket.                               | miniPCIe socket                    |

### User IOs

The following lines of the I/O Expander are available for general purpose use:

| I/O Expander pin name | Signal name | Connector and pin | Digital I/O | IRQ capable | ADC capable |
|-----------------------|-------------|-------------------|-------------|-------------|-------------|
| I03                   | IOEXP_3     | J30 pin 1         | ✓           |             | ✓           |
| I04                   | IOEXP_4     | J30 pin 3         | ✓           |             | ✓           |
| I05                   | IOEXP_5     | J30 pin 4         | ✓           |             | ✓           |

| I/O Expander pin name | Signal name       | Connector and pin | Digital I/O | IRQ capable | ADC capable |
|-----------------------|-------------------|-------------------|-------------|-------------|-------------|
| IO6                   | IOEXP_6           | J30 pin 2         | ✓           |             |             |
| IO37                  | IOEXP_37          | J30 pin 6         | ✓           | ✓           |             |
| IO32                  | EXP_I2C_GPIO/IO32 | J28 pin 5         | ✓           | ✓           |             |

### Digital I/Os

All I/O Expander lines can be configured as digital inputs/outputs and are powered from the 3V3\_IOEXP power rail, directly connected to 3V3.

**Note** Since the GPIOs do not incorporate internal pull-ups or pull-downs, you must add the components to the exterior of the module carrier board.

### I/O Expander IRQs

You can configure a subset of the available I/Os as interrupt inputs and specifically to configure the active edge of the interrupt (rising, falling, or both). When one or more IRQs are activated, the I/O Expander interrupts the main ConnectCore 6UL module through the corresponding IRQ line, signaling the active IRQs in the IRQ status registers. The IRQ inputs can wake the system from any low power mode (suspend or power off).

The I/O Expander uses the IOEXP\_INT\_MCA# line to signal the interrupts to the ConnectCore 6UL SoM, which means that all enabled IRQs in the I/O Expander will wake up the SOM from a sleep status. To prevent this, the IRQs should be masked before suspending the module.

See the [I/O Expander GPIO driver documentation](#) for additional information about how to configure and access its lines.

### Analog to Digital Converter

You can configure a subset of the available I/Os as Analog to Digital channels. The index of the MCA ADC channels corresponds to the index of the IO listed. This means that the ADC channel 3 corresponds to the IO3 signal, the ADC channel 4 to the IO4, and so on.

The result of the ADC conversion for a given input voltage is inversely proportional to the reference voltage of the ADC. For the I/O Expander in the ConnectCore 6UL SBC, the reference voltage corresponds to the 3V3\_IOEXP voltage. (Note that it is a different voltage reference than the ConnectCore 6UL MCA ADCs.) The ADCs provide 12-bit resolution with right-justified, unsigned format output. They are suitable for low-frequency sampling (under 10 Hz). For higher frequency sampling, Digi recommends the CPU ADC channels.

See the [I/O Expander software documentation](#) for additional information about how to configure and access the I/O Expander ADCs.

### Other peripherals

#### User LED

The I/O Expander controls a LED through line USER\_LED1/IO23. You can drive the user LED by configuring this line as a digital output and setting its value.

**XBee Socket**

The following table shows the lines of the I/O Expander that are connected to the XBee socket, allowing more precise control of these modules. However, it is important to note that the actual behavior depends on the XBee version and how it is configured. Refer to the XBee manual reference for more details on how these lines behave.

| I/O Expander pin name | Signal name        | Pin direction | Description   |
|-----------------------|--------------------|---------------|---|
| I07                   | XBEE_RSTN/I07      | Output        | Used for controlling the XBee reset line.                 |
| I09                   | XBEE_SLP_RQ/I09    | Output        | Used for both requesting the XBee to sleep and waking it. |
| I011                  | XBEE_ON/SLP_N/I011 | Input         | Used for reading the power status of the XBee.            |
| I033                  | XBEE_IDENT/I033    | Output        | Used for commissioning of the XBee.                       |

**Parallel Camera**

Lines connected to the parallel camera port control some of its features. Refer to the specific device manual for details on how to interface with these signals.

| I/O Expander pin name | Signal name   | Pin direction | Connector and pin |
|-----------------------|---------------|---------------|-------------------|
| I022                  | CSI_PWDN/I022 | Output        | J17 pin 15        |
| I031                  | CSI_GPIO/I031 | Input/Output  | J17 pin 14        |

**LVDS transceiver**

Two lines connected to the LVDS transceiver control some of its features. Refer to the specific device manuals for details on how to interface with these signals.

| I/O Expander pin name | Signal name             | Pin direction | Description  |
|-----------------------|-------------------------|---------------|--|
| I010/SWD_CLK          | IOEXP_SWD_CLK/LVDS_FLIP | Output        | Connected to LVDS_FLIP pin of the LVDS transceiver. It allows you to reverse the output.                 |
| I013/SWD_DIO          | IOEXP_SWD_DIO/LVDS_RF   | Output        | Connected to LVDS_RF pin of the LVDS transceiver. It allows you to select the input CLK triggering edge. |

**UART 1**

Two signals of the I/O Expander are reserved to be used as a UART. They are connected to an RS-232 level adapter.



**CAUTION!** This functionality is not supported by the current I/O Expander firmware.

| I/O Expander pin name | Signal name      | Pin direction | Connector and pin |
|-----------------------|------------------|---------------|-------------------|
| IO0/UART2_TX          | RS232_IOEXP_2_TX | Output        | J29 pin 1         |
| IO0/UART2_RX          | RS232_IOEXP_2_RX | Input         | J29 pin 2         |

## CAN

The ConnectCore 6UL SBC Pro provides two CAN bus ports compatible with the CAN 2.0B protocol. Two CAN transceivers are used on the SBC to provide transmit and receive capability between the CAN bus and the CAN controller of the i.MX6UL. These transceivers allow signal rates up to 1 Mbps. The CAN\_STBY signal, driven by I/O expander CAN\_STBY/IO34 signal, allows the standby mode for both CAN transceivers simultaneously.

### Pad conflicts

*CAN1 data lines are shared with UART3 flow control lines (CTS and RTS), and CAN2 data lines are shared with UART2 flow control lines. You cannot use CAN1 and UART3 in 4-wire configuration simultaneously.*

The two CAN ports are available on a 6-pin, 1.25 mm pitch expansion connector. The following table shows the pinout of the CAN expansion connector (J27):

| Pin | Signal name | Description               |
|-----|-------------|---------------------------|
| 1   | CAN1_L      | CAN1 bus low signal line  |
| 2   | CAN1_H      | CAN1 bus high signal line |
| 3   | GND         | Ground                    |
| 4   | CAN2_L      | CAN2 bus low signal line  |
| 5   | CAN2_H      | CAN2 bus high signal line |
| 6   | GND         | Ground                    |

Two 120Ω termination resistors are populated on the CAN transceivers:

| Resistor | Description               |
|----------|---------------------------|
| R104     | CAN1 termination resistor |
| R116     | CAN2 termination resistor |

## I2C

The ConnectCore 6UL SBC Pro provides access to an I2C interface. This I2C bus is connected to the I2C1 instance of the i.MX6UL CPU. Two 2.2 K pull-up resistors to a 3.3V power line are populated on the clock and data I2C1 lines. This I2C1 instance communicates with several interfaces on the SBC. The following table shows the interfaces connected to the I2C1 bus and their default I2C addresses:

|               | Interface              | Speed (Kbps) | Address (7-bit)   | Comment   |
|---------------|------------------------|--------------|-------------------|---|
| <b>SBC</b>    | PCIe                   | 100          | -                 |   |
|               | LVDS display touch     | 100          | 0x14 (Fusion 10") | Fusion 7 and Fusion 10 have the same touch controller, which has the same I2C address as Audio codec (0x10). For this reason, a new address for the touch controller has been configured through the Linear Tech LTC4316 address translator that is placed on the Video Adapter Board (not on the SBC). |
|               | Parallel display touch | 100          | 0x14 (Fusion 7")  |   |
|               | CSI camera             | 100          | -                 |   |
|               | Audio codec            | 100          | 0x10              |   |
|               | I/O expander           | 100          | 0x6E              | The I/O Expander address will only be visible if the IC has firmware programmed.  |
|               | NTAG                   | 100          | 0x55              |   |
| <b>Module</b> | PMIC                   | 100          | 0x08              |   |
|               | MCA                    | 100          | 0x7E              |   |
|               | Cryptography chip      | 100          | 0x60              |   |

This I2C1 bus is available on a 6-pin, 1.25 mm pitch expansion connector, which provides access to the following signals:

- I2C1 SDA and SCL lines
- Interruption line
- GPIO

The following table shows the pinout of the I2C1 expansion connector (J28):

| Pin | Signal Name   | Description   |
|-----|---------------|---|
| 1   | EXP_I2C_SCL   | i.MX6UL I2C1 Bus Clock line                                   |
| 2   | EXP_I2C_SDA   | i.MX6UL I2C1 Bus Data line                                    |
| 3   | 3V3           | 3.3V power line   |
| 4   | EXP_I2C_IRQ_N | Interrupt line, connected to i.MX6UL GPIO5_05                 |
| 5   | EXP_I2C_GPIO  | GPIO line, connected to I/O expander EXP_I2C_GPIO/IO32 signal |
| 6   | GND           | Ground  |

## SPI

The ConnectCore 6UL SBC Pro provides an SPI (serial peripheral interface), accessible through an 8-pin, 1.25 mm pitch expansion connector which allows access to the following signals:



- i.MX6UL SPI1 instance
- One slave select line
- Interrupt line

The following table shows the pinout of the SPI expansion connector (J34):

| Pin | Signal name          | Description                                   |
|-----|----------------------|---|
| 1   | 3V3                  | 3.3V power line                               |
| 2   | LCD_DATA20/SPI1_CLK  | SPI clock line                                |
| 3   | LCD_DATA23/SPI1_MISO | SPI <i>Master Input Slave Output</i> line     |
| 4   | LCD_DATA22/SPI1_MOSI | SPI <i>Master Output Slave Input</i> line     |
| 5   | LCD_DATA21/SPI1_SS0  | SPI <i>Slave Select</i> line                  |
| 6   | MCA_IO5              | Connected to on-module MCA                    |
| 7   | SPI1_IRQ_N           | Interrupt line, connected to i.MX6UL GPIO5_08 |
| 8   | GND                  | Ground  |

## GPIO

The ConnectCore 6UL SBC Pro has a 14-pin, 1.25 mm pitch expansion connector, which provides access to several GPIO lines of the i.MX6UL, on-module MCA and I/O expander.

The pinout of the GPIO expansion connector (J30) is shown below:

| Pin | Signal name | Description                    |
|-----|-------------|--------------------------------|
| 1   | IOEXP_3     | Connected to I/O expander      |
| 2   | IOEXP_6     | Connected to I/O expander      |
| 3   | IOEXP_4     | Connected to I/O expander      |
| 4   | IOEXP_5     | Connected to I/O expander      |
| 5   | 3V3         | 3.3V power line                |
| 6   | IOEXP_37    | Connected to I/O expander      |
| 7   | MCA_IO1     | Connected to MCA               |
| 8   | MCA_IO3     | Connected to MCA               |
| 9   | MCA_IO2     | Connected to MCA               |
| 10  | NC          | Not connected                  |
| 11  | EXP_GPIO_1  | Connected to i.MX6UL GPIO1_IO5 |
| 12  | EXP_GPIO_2  | Connected to i.MX6UL GPIO1_IO3 |
| 13  | EXP_GPIO_3  | Connected to i.MX6UL GPIO1_IO2 |
| 14  | GND         | Ground                         |

## UART

The ConnectCore 6UL SBC Pro provides access to three UART ports through a 14-pin, 1.25 mm pitch expansion connector. This connector provides access to the following UART instances:

- I/O expander UART2: 2 wires, RS-232 levels
- i.MX6UL UART3: 4 wires, RS-232 levels
- i.MX6UL UART2: 4 wires, TTL levels (shared with XBee and CAN2 interfaces)

i.MX6UL UART2 and UART3 interfaces have hardware flow control lines (RTS and CTS) while I/O expander UART 2 has just transmission and receiver signals.

The pinout of the UART expansion connector (J29) is shown below:

| Pin | Signal name         | Description                          |
|-----|---------------------|--------------------------------------|
| 1   | RS232_IOEXP_2_TX    | I/O expander UART2 transmission line |
| 2   | RS232_IOEXP_2_RX    | I/O expander UART2 receiver line     |
| 3   | NC                  | Not connected                        |
| 4   | NC                  | Not connected                        |
| 5   | 3V3                 | 3.3V power line                      |
| 6   | RS232_3_TX          | UART3 transmission line              |
| 7   | RS232_3_RX          | UART3 receiver line                  |
| 8   | RS232_3_RTS_N       | UART3 request to send line           |
| 9   | RS232_3_CTS_N       | UART3 clear to send line             |
| 10  | GND                 | Ground                               |
| 11  | UART2_TX            | UART2 transmission line              |
| 12  | UART2_RX            | UART2 receiver line                  |
| 13  | UART2_RTS_N/CAN2_RX | UART2 request to send line           |
| 14  | UART2_CTS_N/CAN2_TX | UART2 clear to send line             |

The RS-232 drivers that manage UART3 and UART2 can be switched off for advanced power management through I/O expander UART\_PWR/IO18 signal.

### Pad conflicts

*CAN1 data lines are shared with UART3 flow control lines (CTS and RTS), and CAN2 data lines are shared with UART2 flow control lines. You cannot use CAN1 and UART3 in 4-wire configuration simultaneously.*

**Note** I/O expander UART2, 2-wire RS-232 port is not supported by default. If your application requires this port, please contact Digi technical support at [www.digi.com/support](http://www.digi.com/support).

## User interfaces

### User LED

The ConnectCore 6UL SBC Pro provides one user LED, which is controlled through the I/O expander.

| LED  | Signal    | Description  |
|------|-----------|--|
| LED1 | USER_LED1 | Yellow LED, controlled by I/O expander USER_LED1/IO23 signal |

## ConnectCore 6UL SBC Pro specifications

---

|                                   |    |
|-----------------------------------|----|
| Electrical specification .....    | 45 |
| Power consumption .....           | 45 |
| Mechanical specification .....    | 46 |
| Environmental specification ..... | 48 |
| WLAN specification .....          | 49 |

## Electrical specification

### Supply voltages

The ConnectCore 6UL SBC Pro has three supply inputs. Two of them power the whole system (ConnectCore 6UL SBC Pro plus the ConnectCore 6UL system-on-module) and the other one powers the RTC of the module when the main supply is not present. The following table shows the voltage range of the input supplies of the ConnectCore 6UL SBC Pro:

| Signal                     | Description                | Min | Typ | Max | Unit |
|----------------------------|----------------------------|-----|-----|-----|------|
| VIN (jack connector)       | Power jack input           | 4.6 | 5.0 | 5.5 | V    |
| VIN (additional connector) | Additional connector input | 4.6 | 5.0 | 5.5 | V    |
| VCC_LICELL                 | Supply for RTC             | 2.4 | -   | 3.6 | V    |

### Power consumption

The power consumption of the entire board (the ConnectCore 6UL SBC Pro plus the ConnectCore 6UL module) has been measured directly through the 5V input power supply. The following table lists power consumption figures measured in the ConnectCore 6UL SBC Pro under specific use cases.

| SBC Power consumption (VIN) |                |          |                          |                |            |
|-----------------------------|----------------|----------|--------------------------|----------------|------------|
| Suspend mode                | Power-off mode | Run-time |                          |                |            |
|                             |                | IDLE     | Display connected (IDLE) | Decoding video | CPU stress |
| 40 mW                       | 2 mW           | 0.84 W   | 2.85 W                   | 3.10 W         | 1.375 W    |

**Note** To better understand the power consumption of the system, see the [ConnectCore 6UL system on module Hardware Reference Manual](#) to see the power consumption of the module (isolated) under the same use cases.

### Use case descriptions

This section describes the use cases that were used to measure power consumption of the ConnectCore 6UL SBC.

#### **Suspend**

System in suspend to RAM mode.



**CAUTION!** You can achieve minimum power consumption numbers by disabling both 3.3V power domains. However, in some applications it may not be possible to switch them off, depending on what they are powering.

**Power-off**

System in power-off with RTC enabled.

**IDLE**

System up and running. Ethernet and wireless disabled.

**Decoding video**

System up and running with the following configuration:

- Ethernet and wireless disabled.
- Fusion7 parallel display connected to the system.

Includes two different use cases:

- Display connected in IDLE mode (without decoding video).
- CPU decoding video.

**CPU stress**


System up and running with the following configuration:

- One Ethernet interface up and linked. The other one disabled.
- USB connected to the system.
- Hanoi application running (Hanoi application stresses the CPU and put it at 100% work load).


## Mechanical specification

The ConnectCore 6UL SBC Pro is a 100mm x 72mm pico-ITX board. Four 3.2mm drills are located on the four corners of the PCB for assembling the board into an enclosure. These drills have a 5.5mm round metalized area for the screws and nuts. The board has four 2.6mm drills to assembly a half size or a full size PCI express mini card module. These drills have a 5.8mm x 5.8mm square metalized area for the screws and nuts. There must be a recess in the board to accommodate the components on the bottom side of the SOM. All dimensions on the following pictures are in millimeters.


### Top view



### Bottom view



### Profile view



## Environmental specification

The operating temperatures defined for the ConnectCore 6UL are as follows:

| Specification | Operating temperature |
|---------------|-----------------------|
| Industrial    | -40°C to +85°C        |



## WLAN specification

For a complete WLAN specification please refer to the [ConnectCore 6UL System-on-Module Hardware Reference Manual](#).

## Known issues

---

Known issue: Connecting Fusion 7" display causes system to wake from suspend mode .....51


## Known issue: Connecting Fusion 7" display causes system to wake from suspend mode

The LCD interface in the ConnectCore 6UL SBC Pro causes the system to wake up from suspend mode when the Fusion 7" display is connected.

### Affected versions/models

This issue is related to a population option that affects the first kits and prototypes of the ConnectCore 6UL SBC Pro, meaning **any board revision prior to revA**.

To check the board version of your SBC Pro, look for the part number in the label as shown in the following photo.



The board shown in the photo is a 2P revision, which precedes revA and therefore exhibits the issue described in this section.

### Description

Two pull-up resistors (R78 and R168) are placed in the interrupt line of the LCD interface (LCD\_IRQ\_N) that goes to both the LCD and the LVDS connectors. The interrupt line of the touch controller in the Fusion 7" display is rising-edge active and should not be driven by the carrier board. When going to suspend to RAM mode, the LCD\_IRQ\_N line must be kept low in order to avoid waking the system up.

However, the Fusion 7" display is not managing it properly, and the pull-ups generate the rising-edge event that wakes the system from suspend mode.


---

**Note** This issue is not exclusive to the Fusion 7" display; it can potentially occur with any touch controller. Check the interrupt line of the LCD interface (LCD\_IRQ\_N) in your carrier board for this wake-from-suspend behavior.

---

### Workaround/fix

Remove the following resistors from your ConnectCore 6UL SBC Pro before connecting the Fusion 7" display:



### Design recommendation

When connecting any display to this interface, make sure that the LCD\_IRQ\_N line is properly driven by the display. If it is not, Digi recommends that you pull the display touch interrupt line up or down depending on the polarity of the touch controller interrupt (pull down if rising-edge active, pull up if falling-edge active).

## Regulatory information

---

|  |    |
|--|----|
| Maximum power and frequency specifications ..... | 54 |
| Europe .....                                     | 54 |

## Maximum power and frequency specifications

**Note** The following maximum power and frequency values are for the ConnectCore 6UL system-on-module.

| Maximum power | Frequencies  |
|---------------|--|
| 63.1 mW       | 13 overlapping channels each 22 MHz wide and spaced at 5 MHz. Centered at 2.412 to 2.472 MHz.      |
| 31.62 mW      | 165 overlapping channels each 22 or 40 MHz wide and spaced at 5 MHz. Centered at 5180 to 5825 MHz. |

## Europe

### Declarations of Conformity

Digi has issued Declarations of Conformity for the ConnectCore 6UL SBC Pro concerning emissions, EMC, and safety. For more information, see <http://www.digi.com/resources/certifications>.

#### Important note

Digi customers assume full responsibility for learning and meeting the required guidelines for each country in their distribution market. Refer to the radio regulatory agency in the desired countries of operation for more information.

### CE mark


The ConnectCore 6UL SBC Pro is certified for use in several European countries. For information, visit [www.digi.com/resources/certifications](http://www.digi.com/resources/certifications).

If the ConnectCore 6UL SBC Pro is incorporated into a product, the manufacturer must ensure compliance of the final product with articles 3.1a and 3.1b of the RE Directive (Radio Equipment Directive). A Declaration of Conformity must be issued for each of these standards and kept on file as described in the RE Directive (Radio Equipment Directive).

Furthermore, the manufacturer must maintain a copy of the ConnectCore 6UL SBC Pro user manual documentation and ensure the final product does not exceed the specified power ratings, antenna specifications, and/or installation requirements as specified in the user manual. If any of these specifications are exceeded in the final product, a submission must be made to a notified body for compliance testing to all required standards.

#### OEM labeling requirements

The CE marking must be affixed to a visible location on the OEM product.

**CE labeling requirements**

The CE mark shall consist of the initials “CE” taking the following form:

- If the CE marking is reduced or enlarged, the proportions given in the above graduated drawing must be respected.
- The CE marking must have a height of at least 5mm except where this is not possible on account of the nature of the apparatus.
- The CE marking must be affixed visibly, legibly, and indelibly.